

Builders Film Data Sheet



Used for:

- Concrete underlay
- Moisture barrier
- Covering equipment
- Landscaping
- Protection sheet - etc

Description

Polyethylene film using recycled resins or virgin low density polyethylene resins.

Suited for use as a damp proof membrane or vapour barrier.

Black plastic rolls 200um gauge for medium or high impact resistance uses.

Builders films are manufactured to comply with the requirements of Australian Standard 2870.

Installation Instructions

Any Builders Film used as a vapour barrier and or as a damp proof membrane must be installed in accordance with Australian Standard 2870

The builders film shall be placed on the subbase under the concrete slab.

Overlapping should be not less than 200mm to ensure continuousness, and duct tape should be used to secure the full length in place.

Take care to ensure any pipes or services are sealed off by taping with duct tape as well to ensure a continuous moisture barrier.

Disclaimer

This data sheet has been written to our best knowledge. It includes potential uses and application based on information available to us at the time. Our responsibility for products sold is subject to our terms and conditions of sale. CAGroup does not accept any liability either directly or indirectly for any losses suffered in connection with the use or application of the product whether or not in accordance with any advice, specification, recommendation or information given.